

X5 and X6 Series 4 Head Filler with Crowners are available with an optional Accumulation Pack off Table and with Integrated Temperature and Pressure Sensing.

Option 1 Universal Semi automatic 4 head Filler Capper Without accumulation pack off table

Our universal Counter pressure bottle fillers offer the greatest flexibility amongst any bottle filler available. Designed to fill and cap any size bottle on the same platform with minimal Change over parts.



See Specs and pricing Below

Option 2

Universal 4 head filler capper with Accumulation Pack off Table



See Specs next page and pricing Below

Equipment Specifications for both X5-X6 Series

PLC controlled

The onboard logic controller automatically advances bottles between the fill heads, crowners and pack off table while carrying out other essential automated operations. Automated Bottle pre-evacuation of air by use of vacuum, bottle CO₂ purging, CO₂ bottle counter pressure and bottle Capping.

Touch Screen Interface

The screen interface allows the operator to start or stop the filling cycle, adjust the settings of the Pre-evac purge cycles, engage CIP and Crowner operation. A diagnostic screen is also included for individual machine component testing.

The **X6** fillers feature additional screen read out to display product inlet temperature, tank pressure, bottle pressure and additional diagnostics for system leak detection.

CIP Mode

All ports and points of product contact can be flushed Cleaned and sanitized on the filler using the **included** CIP pump.

Operator controlled

The operator of the filler simply initiates the start of the automated filling cycles with a joystick or the screen interface. The filler will automatically open and close all of the necessary valves for bottle filling. Only loading and unloading the bottles on the filler and placing the crowns on the crowner heads for capping is necessary prior to restarting the next cycle.

Fill Rate Example Fill rates are influenced by product temperature product carbonation levels and pre evac/purge settings.

16 bpm 12oz and 12 bpm 500ml typical fill speeds.

Continued next page

Dimensions

4 Head Filler without accumulation table

55.5" L x 28" W x 78" H

141cm L x 71cm W x 200cm H

Deck Height 36" (91.5 CM)

4 Head Filler with accumulation table

55.5" L x 40" W x 78" H

141cm L x 102cm W x 200cm H

Deck Height 36" (91.5 CM)

System Requirements

Compressed CO2

11.5 cfm @ 90 PSI air supply (3.7 HP 60 gallon air compressor) recommended

110v/220v AC 50/60 hz

X5 Series Universal 4 Head Filler Capper

\$12,500 Without Pack Off Table

\$13,500 With Integrated Accumulation Pack Table

X6 Series Includes all features of the X5 Series with Integrated Temperature and Pressure sensing

\$14,500 Without Pack Off table

\$15,500 With Integrated Accumulation Pack Table

-All fillers include all necessary change over parts for 2 bottle sizes.

-Additional change parts \$550 per bottle size.

-Some bottles may require additional change parts and design services and are subject to additional costs.

-All pricing in USD, applicable taxes, freight, packing/crating, customs/duties, are subject to additional costs.

-Terms are 50% down at time of order and remainder prior to shipment.